

Seater Head 4,30/.170-R36

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 4,30/.170-R36
- Manufacturer: TRIEBEL
- Product no.: EU2017373
- Mfr. No.: 3000054V-04.30-R036
- Diameter (in): 0.170
- Diameter mm: 4,30
- Radius: R36
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-04.30-R036

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 4,30/.170R36. This product is designed for precision bullet seating and is made from highquality brass. To ensure your safety and the optimal performance of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure the Seater Head is used only for its intended purpose.
- Always handle the Seater Head with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of damage or wear.
- Report any unsafe products or incidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Seater Head.
- Avoid using the Seater Head in wet or damp conditions to prevent electrical hazards.
- Ensure that the Seater Head is securely attached to the reloading die before use.
- Do not exceed the recommended specifications for the Seater Head to prevent malfunctions.
- Be cautious of sharp edges and points when handling the Seater Head.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the reloading die.
- Insert the Seater Head into the die, ensuring a snug fit.
- Tighten the locking mechanism to secure the Seater Head in place.

2. Usage:

- Prepare your cartridges according to the manufacturer's specifications.
- Place a cartridge case into the reloading press.
- Adjust the seating depth according to your requirements.
- Gently lower the press handle to seat the bullet.
- Inspect the seated bullet for proper alignment and depth.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in general waste if it is damaged or no longer functional.
- Recycle the Seater Head if possible, following local recycling guidelines.

Contact Information for Further Support

For any inquiries regarding the safety or usage of the Seater Head, please refer to the manufacturer's website or contact their customer support.

Thank you for your attention to these safety instructions. Your safety is our priority, and we hope you enjoy using the Seater Head 4,30/.170R36.