

Seater Head 4,60/.181-R11

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 4,60/.181-R11
- Manufacturer: TRIEBEL
- Product no.: EU2017374
- Mfr. No.: 3000054V-04.60-R011
- Diameter (in): 0.181
- Diameter mm: 4,60
- Radius: R11
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-04.60-R011

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 4,60/.181R11 from TRIEBEL. This product is designed for precision bullet seating and is manufactured from highquality brass using modern CNC machining techniques. To ensure safe and effective use, please carefully read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always use the Seater Head according to the manufacturer's instructions.
- Ensure that the product is compatible with your reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for signs of wear or damage before use.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Improper use can lead to misalignment and inaccurate bullet seating.
 - Risk of injury from sharp edges or small parts.
- **Avoiding Hazards:**
 - Always wear appropriate safety gear, such as safety glasses and gloves.
 - Make sure the working area is clean and welllit.
 - Do not use the Seater Head if it is damaged or not functioning correctly.
 - Follow loading instructions carefully to avoid overpressure situations.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure that your reloading press is turned off and unplugged.
 2. Remove any existing seater head from your die set.
 3. Carefully install the Seater Head 4,60/.181R11 into the die set, ensuring it is securely tightened.
 4. Check for proper alignment with the reloading press.
- **Usage:**
 1. Select the correct seater head using the tool on the manufacturer's website at www.tribelreloading.com.
 2. Prepare your cartridges according to standard reloading practices.
 3. Insert the bullet into the cartridge case.
 4. Operate the reloading press to gently seat the bullet using the Seater Head.
 5. Inspect each cartridge for proper seating depth and alignment.

Disposal Instructions

- Dispose of the Seater Head responsibly, following local regulations for metal recycling.
- Do not throw the product in regular household waste.
- Ensure that any damaged parts are disposed of safely to prevent injury.

Contact Information for Further Support

For any questions or concerns regarding safety or product usage, please refer to the manufacturer's website or contact the appropriate support channels as provided by the manufacturer.

Thank you for your attention to these safety instructions. Your safety is our priority, and we appreciate your commitment to using our products responsibly.