

Seater Head 4,60/.181-R13

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 4,60/.181-R13](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017375
- Mfr. No.: 3000054V-04.60-R013
- Diameter (in): 0.181
- Diameter mm: 4,60
- Radius: R13
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-04.60-R013

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 4,60/.181R13. This guide provides essential safety instructions and guidelines to ensure safe and effective use of the product. Please read this manual carefully before use to understand the safety precautions and proper handling of the Seater Head.

General Safety Guidelines

- Ensure the Seater Head is used in accordance with the manufacturer's instructions.
- Always inspect the Seater Head for damage or wear before use.
- Keep the Seater Head out of reach of children and pets.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses and gloves, when using the Seater Head.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Avoid forcing the Seater Head into the die, as this may cause damage or injury.
- Ensure proper alignment of the bullet and cartridge before seating to prevent misfires or accidents.
- Do not use the Seater Head if you are unsure about the setup or operation.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your workspace is clean and welllit.
- Gather all necessary tools and components, including the Seater Head and compatible die.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Inspect the Seater Head for any visible damage.
- Insert the Seater Head into the die according to the manufacturer's instructions.
- Secure the Seater Head in place, ensuring it is properly aligned.

3. Usage:

- Place the bullet and cartridge in the die.
- Gently lower the press handle to seat the bullet.
- Check for proper seating and alignment after each operation.
- If any issues arise, stop using the Seater Head immediately and consult the troubleshooting section or contact support.

Disposal Instructions

- Dispose of the Seater Head responsibly at the end of its life cycle.
- Follow local regulations for the disposal of metal products.
- Do not dispose of the Seater Head in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website for support resources and contact information.

This safety instruction guide is designed to help you use the Seater Head safely and effectively. By following these guidelines, you contribute to a safer environment for yourself and others. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk