

Seater Head 4,60/.181-R21

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 4,60/.181-R21](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017376
- Mfr. No.: 3000054V-04.60-R021
- Diameter (in): 0.181
- Diameter mm: 4,60
- Radius: R21
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-04.60-R021

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 4,60/.181R21. This product is designed to enhance your reloading experience by providing precise and gentle bullet seating. It is essential to follow safety guidelines to ensure safe usage and to maximize the performance of the product.

General Safety Guidelines

- Ensure that you read and understand all safety instructions prior to using the Seater Head.
- Always use the Seater Head in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Store the Seater Head in a dry, cool place to prevent corrosion or damage.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading equipment.
- Ensure that the reloading area is wellventilated and free from clutter.
- Do not exceed the recommended specifications for the Seater Head.
- Avoid using the Seater Head with incompatible dies or components.
- Be cautious of sharp edges and moving parts during operation.
- Do not modify the Seater Head in any way, as this may compromise safety and performance.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Use the tool on the manufacturer's website www.triebelreloading.com to select the appropriate seater head for your specific needs.

2. Installation:

- Ensure that your reloading die is clean and free from debris.
- Carefully remove the existing seater head if applicable.
- Install the Seater Head by following the die manufacturer's instructions.
- Ensure that the Seater Head is securely fastened and properly aligned.

3. Usage:

- Load the cartridge case into the reloading press as per the manufacturer's instructions.
- Adjust the seating depth according to your specifications.
- Operate the reloading press smoothly and steadily to ensure consistent bullet seating.
- Inspect each cartridge after seating to ensure proper alignment and depth.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste. Check for designated disposal locations or recycling programs in your area.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact their customer service for assistance.

Thank you for prioritizing safety and compliance while using the Seater Head. Enjoy your reloading experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk