

Seater Head 4,60/.181-R25

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 4,60/.181-R25
- Manufacturer: TRIEBEL
- Product no.: EU2017377
- Mfr. No.: 3000054V-04.60-R025
- Diameter (in): 0.181
- Diameter mm: 4,60
- Radius: R25
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-04.60-R025

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 4,60/.181R25. This product is designed for precision bullet seating and is made from highquality brass. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the Seater Head is compatible with your reloading dies from Triebel Waffenwerkzeuge.
- Always follow the manufacturer's instructions for use and maintenance.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any signs of damage or wear before use.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Personal Safety:** Always wear appropriate safety gear, such as safety glasses and gloves, when handling reloading equipment.
- **Work Environment:** Use the Seater Head in a wellventilated area to minimize exposure to any potential fumes or debris.
- **Storage:** Store the Seater Head in a cool, dry place away from direct sunlight and moisture.
- **Handling:** Handle the Seater Head with care to avoid dropping or damaging it.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Use the tool available on the manufacturer's website (www.triebelreloading.com) to select the appropriate Seater Head for your needs.

2. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Remove the existing seater head from your reloading die.
- Insert the Seater Head 4,60/.181R25 into the die and secure it tightly.

3. Usage:

- Follow the reloading instructions specific to your equipment.
- Ensure that the bullet is properly aligned with the Seater Head before operation.
- Operate the reloading press smoothly to achieve precise bullet seating.

4. PostUse Care:

- Clean the Seater Head after each use to prevent residue buildup.
- Store the Seater Head in its original packaging or a designated storage container.

Disposal Instructions

- Dispose of the Seater Head according to local regulations for metal recycling.
- Do not dispose of the product in regular household waste.

Contact Information for Further Support

For any safety inquiries or further support, please refer to the manufacturer's website or contact your local distributor.

By adhering to these guidelines, you can ensure a safe and effective experience with your Seater Head. Thank you for your attention to safety!