

## Seater Head 4,60/.181-R25

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website [www.triebel-reloading.com](http://www.triebel-reloading.com). Suitable for original dies from Triebel Waffenwerkzeuge.



### Attributes

- Name: [Seater Head 4,60/.181-R25](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017377
- Mfr. No.: 3000054V-04.60-R025
- Diameter (in): 0.181
- Diameter mm: 4,60
- Radius: R25
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-04.60-R025

# Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

# Seater Head Safety Instruction Guide

## Introduction

Thank you for choosing the Seater Head 4,60/.181R25. This product is designed for precision bullet seating and is made from highquality brass. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

## General Safety Guidelines

- Ensure that the Seater Head is compatible with your reloading dies from Triebel Waffenwerkzeuge.
- Always follow the manufacturer's instructions for use and maintenance.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any signs of damage or wear before use.
- Report any unsafe products or accidents to the appropriate authorities.

## Specific Safety Precautions for Use

- **Personal Safety:** Always wear appropriate safety gear, such as safety glasses and gloves, when handling reloading equipment.
- **Work Environment:** Use the Seater Head in a wellventilated area to minimize exposure to any potential fumes or debris.
- **Storage:** Store the Seater Head in a cool, dry place away from direct sunlight and moisture.
- **Handling:** Handle the Seater Head with care to avoid dropping or damaging it.

## Instructions for Installation and Usage

### 1. Selecting the Correct Seater Head:

- Use the tool available on the manufacturer's website ([www.triebelreloading.com](http://www.triebelreloading.com)) to select the appropriate Seater Head for your needs.

### 2. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Remove the existing seater head from your reloading die.
- Insert the Seater Head 4,60/.181R25 into the die and secure it tightly.

### 3. Usage:

- Follow the reloading instructions specific to your equipment.
- Ensure that the bullet is properly aligned with the Seater Head before operation.
- Operate the reloading press smoothly to achieve precise bullet seating.

### 4. PostUse Care:

- Clean the Seater Head after each use to prevent residue buildup.
- Store the Seater Head in its original packaging or a designated storage container.

## Disposal Instructions

- Dispose of the Seater Head according to local regulations for metal recycling.
- Do not dispose of the product in regular household waste.

## **Contact Information for Further Support**

For any safety inquiries or further support, please refer to the manufacturer's website or contact your local distributor.

By adhering to these guidelines, you can ensure a safe and effective experience with your Seater Head. Thank you for your attention to safety!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)