

Seater Head 4,60/.181-R48

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 4,60/.181-R48
- Manufacturer: TRIEBEL
- Product no.: EU2017378
- Mfr. No.: 3000054V-04.60-R048
- Diameter (in): 0.181
- Diameter mm: 4,60
- Radius: R48
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-04.60-R048

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 4,60/.181R48. This product is designed for precise and gentle bullet seating in reloading applications. To ensure your safety and the optimal performance of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure the working area is clean, dry, and welllit to prevent accidents.
- Keep the Seater Head and all reloading equipment out of reach of children and unauthorized users.
- Inspect the Seater Head for any damage or wear before use. Do not use if damaged.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE), including safety glasses and gloves, while handling and using the Seater Head.
- Ensure that your reloading press is compatible with the Seater Head before installation.
- Avoid wearing loose clothing or jewelry that may become caught in the reloading equipment.
- Do not exceed the recommended specifications for bullet seating to avoid potential hazards.
- Be aware of the potential hazards associated with handling ammunition components and follow all safety protocols.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials, including the Seater Head, reloading press, and compatible dies.
- Ensure your working area is clean and organized.

2. Installation:

- Disconnect the reloading press from any power source.
- Remove the existing seater head from the reloading die by following the manufacturer's instructions.
- Carefully install the Seater Head into the die, ensuring it is securely fastened.
- Reconnect the reloading press to the power source if applicable.

3. Usage:

- Follow the manufacturer's guidelines for bullet seating, ensuring that the bullet is properly aligned with the Seater Head.
- Operate the reloading press smoothly and steadily to achieve consistent results.
- Monitor the seating process closely to ensure accuracy and safety.

4. PostUsage:

- After use, clean the Seater Head and surrounding area to remove any debris or residue.
- Store the Seater Head in a safe place, away from children and unauthorized users.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of in regular household waste if it contains hazardous materials.
- Contact local waste management authorities for guidance on safe disposal options.

Contact Information for Further Support

For any inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website or contact your local distributor. Always ensure that you are following the latest safety guidelines and product updates.

By adhering to these safety instructions, you can ensure a safer reloading experience while maximizing the performance of your Seater Head. Thank you for prioritizing safety in your reloading practices.