

Seater Head 5,45/.215-R32

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 5,45/.215-R32
- Manufacturer: TRIEBEL
- Product no.: EU2017379
- Mfr. No.: 3000054V-05.45-R032
- Diameter (in): 0.215
- Diameter mm: 5,45
- Radius: R32
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.45-R032

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 5,45/.215R32 by TRIEBEL. This guide provides essential safety information and instructions to ensure the safe use of your product. Please read this manual carefully before using the seater head.

General Safety Guidelines

- Always use the seater head in accordance with the manufacturer's instructions.
- Ensure that the seater head is compatible with your reloading equipment.
- Store the seater head in a safe place, out of reach of children and pets.
- Regularly inspect the seater head for signs of wear or damage before each use.
- Do not use the seater head if it appears damaged or if any parts are missing.
- Follow all local laws and regulations regarding ammunition reloading and the use of reloading equipment.

Specific Safety Precautions for Use

- Handle all reloading components, including the seater head, with care to avoid injury.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when reloading.
- Keep your workspace clean and organized to prevent accidents.
- Ensure that the area is wellventilated when reloading to avoid inhaling any harmful substances.
- Avoid distractions while using the seater head to maintain focus and precision.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Carefully remove the existing seater head from your reloading die.
- Align the new Seater Head 5,45/.215R32 with the die and screw it into place securely.
- Doublecheck that the seater head is properly seated and aligned.

2. Usage:

- Set up your reloading press according to the manufacturer's instructions.
- Use the tool on the manufacturer's website (www.triebelreloading.com) to select the correct seater head for your specific needs.
- Follow the reloading procedure recommended for your specific caliber and bullet type.
- Monitor the seating depth and bullet alignment during the reloading process to ensure accuracy.

Disposal Instructions

- Dispose of any damaged or worn seater heads in accordance with local regulations.
- Do not discard any reloading components in regular household waste.
- Check with local waste management authorities for proper disposal methods for metal and ammunition components.

Contact Information for Further Support

For safety inquiries or additional support regarding the Seater Head 5,45/.215R32, please refer to the

manufacturer's website or contact your local distributor.

Conclusion

By following the safety guidelines and instructions outlined in this guide, you can ensure a safe and effective reloading experience with your Seater Head 5,45/.215R32. Stay informed about safety recalls and updates through the EU's Safety Gate platform, and report any unsafe products or accidents to the relevant authorities. Thank you for prioritizing safety in your reloading practices.