

Seater Head 5,45/.215-R61

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 5,45/.215-R61
- Manufacturer: TRIEBEL
- Product no.: EU2017380
- Mfr. No.: 3000054V-05.45-R061
- Diameter (in): 0.215
- Diameter mm: 5,45
- Radius: R61
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.45-R061

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 5,45/.215R61. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- **Product Safety:** This product has been designed to ensure safe use in accordance with EU regulations. Use it only as intended.
- **Enhanced Recalls:** In case of any safety issues, recall notices will be provided. Please stay informed about potential recalls.
- **Online Shopping:** When purchasing online, ensure that you are buying from authorized sellers who comply with safety requirements.
- **Special Consumer Focus:** This product is not intended for use by children. Keep it out of reach of minors.
- **EU Contact Point:** For any safety inquiries, please refer to the contact information provided by the manufacturer.
- **Rapid Alerts:** Stay updated on product safety by checking the EU's Safety Gate platform for any alerts regarding unsafe products.

Specific Safety Precautions for Use

- **Read Instructions:** Always read the user manual before using the Seater Head to ensure proper handling and operation.
- **Wear Safety Gear:** Use appropriate safety equipment, such as safety glasses and gloves, while handling the product.
- **Inspection:** Before each use, inspect the Seater Head for any damage or wear. Do not use if damaged.
- **Proper Handling:** Handle the Seater Head with care to avoid injury or damage to the product.
- **Avoid Overloading:** Do not exceed the recommended specifications for use, as this may lead to malfunction or accidents.
- **Keep Workspace Clear:** Maintain a clean and organized workspace to prevent accidents during use.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure the workspace is clean and free of obstructions.
 2. Follow the instructions on the manufacturer's website to select the correct seater head for your specific needs.
 3. Securely attach the Seater Head to your reloading die according to the manufacturer's guidelines.
 4. Doublecheck all connections to ensure stability before use.
- **Usage:**
 1. Prepare your cartridges according to the reloading guidelines.
 2. Place the bullet into the case mouth and align it with the Seater Head.
 3. Gently press down to seat the bullet, ensuring it is aligned properly.
 4. Check the seating depth to ensure it meets your specifications.
 5. Repeat the process for each cartridge, maintaining consistent pressure and alignment.

Disposal Instructions

- **Environmental Considerations:** Dispose of the Seater Head and any associated materials in accordance with local regulations.
- **Recycling:** If possible, recycle brass components to minimize environmental impact.
- **Hazardous Waste:** Do not dispose of the product in regular household waste if it is damaged or contains hazardous materials. Check with local waste management for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or your point of purchase for assistance.