

Seater Head 5,60/.223-K10,3

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 5,60/.223-K10,3
- Manufacturer: TRIEBEL
- Product no.: EU2017381
- Mfr. No.: 3000054V-05.60-K10.3
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: K10
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-K10.3

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 5,60/.223K10,3. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully. It is essential to follow all guidelines to protect yourself and others while using this product.

General Safety Guidelines

- Always ensure the product is compatible with your reloading equipment.
- Inspect the seater head for any signs of damage before use.
- Use the product only for its intended purpose as specified by the manufacturer.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Regularly check for updates on product recalls via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Personal Protective Equipment (PPE):** Always wear appropriate safety gear, including safety glasses and gloves, when handling the seater head.
- **Avoiding Hazards:**
 - Do not exceed the recommended specifications for bullet seating.
 - Ensure a stable work surface to prevent accidents during use.
 - Avoid distractions while using the seater head to maintain focus.
- **Handling and Storage:**
 - Store the product in a dry place, away from moisture and extreme temperatures.
 - Handle the seater head with care to prevent bending or damaging the precision components.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading die is clean and free from debris.
- Carefully screw the seater head into the reloading die until it is securely in place. Do not overtighten.
- Verify that the seater head is properly aligned with the die.

2. Usage:

- Prepare your cartridge cases according to standard reloading procedures.
- Insert the bullet into the case mouth and position it under the seater head.
- Gradually lower the ram of the reloading press to seat the bullet. Monitor the process to ensure proper alignment.
- After seating, inspect the cartridge for proper bullet depth and alignment.

3. PostUse Care:

- Clean the seater head after each use to prevent residue buildup.
- Store the seater head in its original packaging or a designated storage container.

Disposal Instructions

- Dispose of any damaged or wornout seater heads according to local regulations for hazardous waste.
- Do not throw the product in regular household waste to ensure environmental safety.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head 5,60/.223K10,3, please refer to the manufacturer's website for additional support and resources.