

Seater Head 5,60/.223-R21

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 5,60/.223-R21](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017383
- Mfr. No.: 3000054V-05.60-R021
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R21
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R021

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 5,60/.223R21. This product is designed for precision bullet seating in reloading applications. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any signs of wear or damage before use.
- Use the Seater Head only in wellventilated areas to avoid inhalation of any dust or particles.
- Keep the Seater Head and all reloading components out of reach of children and pets.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling reloading components.
- Do not exceed the recommended specifications for bullet seating, as this may result in dangerous conditions.
- Ensure that your reloading press is securely mounted and stable before using the Seater Head.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.
- Be cautious of hot surfaces; parts of the reloading equipment may become hot during use.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and unplugged.
- Remove any existing seater head from the reloading die.
- Clean the die threads to ensure a proper fit.
- Carefully screw the Seater Head into the die until it is snug. Do not overtighten.
- Verify that the Seater Head is aligned correctly with the reloading press.

2. Usage

- Prepare your cartridges and bullets as per the manufacturer's guidelines.
- Set the desired seating depth according to your specifications.
- Insert a cartridge case into the reloading press.
- Place a bullet on top of the cartridge case.
- Engage the press handle smoothly to seat the bullet. Avoid sudden or excessive force.
- Inspect the completed cartridge for proper seating and alignment.

Disposal Instructions

- Dispose of any damaged or worn components in accordance with local waste disposal regulations.
- Do not dispose of reloading materials in regular household waste. Follow guidelines for hazardous materials if applicable.
- Recycle any brass components where facilities are available.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's website or contact the appropriate EU-based support channels.

Thank you for prioritizing safety while using the Seater Head 5,60/.223R21. Your adherence to these guidelines helps ensure a safe and enjoyable reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk