

Seater Head 5,60/.223-R28

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 5,60/.223-R28
- Manufacturer: TRIEBEL
- Product no.: EU2017384
- Mfr. No.: 3000054V-05.60-R028
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R28
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R028

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 5,60/.223R28. This product is designed for precise and gentle bullet seating, ensuring optimal performance in your reloading activities. Please read this safety instruction guide carefully to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always ensure the product is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Use the product only for its intended purpose to avoid accidents.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Check for any recall updates on the EU's Safety Gate platform to stay informed about product safety.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading equipment.
- Handle all components with care to prevent injury.
- Always wear appropriate safety gear, such as safety glasses and gloves, when handling reloading equipment.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Avoid using the product if you notice any defects or irregularities.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is clean and free from debris.
- Securely attach the Seater Head to your reloading press following the manufacturer's instructions.
- Verify that the Seater Head is properly aligned before use.

2. Usage:

- Select the correct seater head using the tool on the manufacturer's website at www.tribelreloading.com.
- Load the appropriate bullet into the cartridge case.
- Adjust the seating depth according to your reloading specifications.
- Operate the reloading press smoothly to ensure precise bullet seating.
- After use, clean the Seater Head to maintain its performance.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal recycling.
- Do not dispose of the product in household waste.
- Ensure that any worn or damaged components are disposed of safely to prevent environmental harm.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please consult the manufacturer's website or contact their support team for assistance.