

Seater Head 5,60/.223-R37

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 5,60/.223-R37
- Manufacturer: TRIEBEL
- Product no.: EU2017386
- Mfr. No.: 3000054V-05.60-R037
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R37
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R037

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 5,60/.223R37, a highquality product designed for precise and gentle bullet seating. This guide provides important safety instructions and usage information to ensure your safety and the effective use of this product.

General Safety Guidelines

- Always read and understand the instructions before using the product.
- Ensure that the Seater Head is used only with compatible equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Check the EU's Safety Gate platform for any recall updates related to this product.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - The Seater Head may have sharp edges; handle with care.
 - Improper use can lead to misalignment and potential injury.
- **Avoiding Hazards:**
 - Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Seater Head.
 - Ensure that the workspace is clean and free of obstructions.
 - Do not exceed the recommended specifications for use.
- **Agesspecific Warnings:**
 - This product is intended for use by individuals aged 18 and older. Keep away from children.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure the die is clean and free from debris.
 2. Carefully screw the Seater Head into the die until it is securely in place.
 3. Adjust the Seater Head to the desired depth according to your specifications.
- **Usage:**
 1. Load the cartridge into the reloading press.
 2. Align the bullet with the Seater Head.
 3. Apply gentle pressure to seat the bullet into the cartridge.
 4. Inspect the cartridge for proper seating and alignment.
 5. Repeat the process for additional cartridges.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal waste.
- Do not dispose of the product in household waste.
- If the product is damaged or no longer usable, ensure it is recycled or disposed of safely.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please reach out to the manufacturer or the designated EU contact point for assistance.

By following these safety instructions, you can ensure a safe and effective experience with your Seater Head 5,60/.223R37. Thank you for your attention to these important guidelines.