

Seater Head 5,60/.223-R47

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 5,60/.223-R47
- Manufacturer: TRIEBEL
- Product no.: EU2017387
- Mfr. No.: 3000054V-05.60-R047
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R47
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R047

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 5,60/.223R47. This guide provides essential safety instructions and usage information to ensure your safe and effective use of this product. Please read this guide carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose.
- Always follow the manufacturer's instructions for installation and usage.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for wear or damage before each use.
- If you notice any defects or irregularities, discontinue use immediately and consult the manufacturer.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the Seater Head.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Avoid using excessive force during the bullet seating process to prevent damage to the Seater Head or the cartridge.
- Ensure that the working area is clean and free of obstructions to avoid accidents.
- Do not modify the Seater Head in any way, as this may lead to unsafe conditions.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Select the appropriate Seater Head for your cartridge using the tool available on the manufacturer's website.
- Carefully screw the Seater Head into the die body, ensuring a snug fit without overtightening.

2. Usage:

- Prepare your cartridges according to the manufacturer's specifications.
- Place the cartridge case into the reloading press.
- Align the bullet with the Seater Head and gently lower the ram to seat the bullet.
- Monitor the process closely to ensure proper seating depth and alignment.
- After use, clean the Seater Head to remove any debris or residue.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in household waste if it is damaged or defective.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's website or contact their customer service.

By following these guidelines, you can help ensure a safe and effective experience with your Seater Head 5,60/.223R47. Thank you for your attention to safety.