

Seater Head 5,60/.223-R50

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 5,60/.223-R50
- Manufacturer: TRIEBEL
- Product no.: EU2017388
- Mfr. No.: 3000054V-05.60-R050
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R050

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for purchasing the Seater Head 5,60/.223R50. This guide provides important safety instructions and guidelines to ensure the safe and effective use of this product. Please read this document carefully before use.

General Safety Guidelines

- Ensure that you are familiar with the product and its intended use before operating.
- Always follow the manufacturer's instructions and recommendations.
- Use the product only for its intended purpose as specified in this guide.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for wear and damage before use.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates through the EU Safety Gate platform.

Specific Safety Precautions for Use

- **Hazard Identification:**

- The Seater Head is designed for precision bullet seating. Improper use may lead to misalignment or accidents.
- Always handle the product with care to avoid injury from sharp edges or moving parts.

- **Avoiding Hazards:**

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the product.
- Ensure that the workspace is clean and free from obstructions.
- Do not exceed the recommended specifications for the Seater Head.
- Avoid using damaged or worn components.

- **Age and Audience Specific Warnings:**

- This product is not intended for use by individuals under the age of 18 without adult supervision.
- Ensure that inexperienced users receive adequate training before using the product.

Instructions for Installation and Usage

- **Installation:**

1. Ensure that your workspace is clean and well lit.
2. Verify that you have the correct seater head for your die set using the tool on the manufacturer's website.
3. Carefully attach the Seater Head to the reloading die, ensuring a secure fit.

- **Usage:**

1. Prepare your cartridge case and bullet according to standard reloading practices.
2. Insert the cartridge case into the die and ensure proper alignment.
3. Gently lower the bullet into the case using the Seater Head, ensuring optimal axial alignment.
4. Follow your reloading manual's guidelines for seating depth and pressure.
5. Inspect the completed cartridge for proper seating and alignment before use.

Disposal Instructions

- Dispose of any damaged or worn components in accordance with local regulations.
- Do not dispose of the product in household waste. Check for local recycling programs or hazardous waste disposal facilities.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact your local retailer for assistance. Always keep this guide for future reference.

Thank you for ensuring a safe and effective reloading experience with the Seater Head 5,60/.223R50.