

Seater Head 5,60/.223-R59

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 5,60/.223-R59](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017389
- Mfr. No.: 3000054V-05.60-R059
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R59
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R059

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 5,60/.223R59 from TRIEBEL. This guide provides essential safety information and instructions to ensure the safe and effective use of your product. Please read this guide carefully before using the Seater Head.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose, which is bullet seating in reloading processes.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the Seater Head and all reloading components out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any damage or wear before each use. Do not use if damaged.
- Follow all local regulations and guidelines related to ammunition reloading and storage.

Specific Safety Precautions for Use

- **Hazard Identification:** The Seater Head can pose risks if not used correctly. Potential hazards include:
 - Injury from improper use or handling.
 - Damage to the Seater Head or other reloading components.
- **Avoiding Hazards:**
 - Always ensure that the Seater Head is securely attached to the reloading press before use.
 - Do not exceed the recommended specifications for bullet types and sizes.
 - Use only compatible dies from Triebel Waffenwerkzeuge with the Seater Head.
 - Do not force the bullet into the case; apply gentle and even pressure to avoid damaging the bullet or the Seater Head.

Instructions for Installation and Usage

- **Installation:**
 1. Ensure that your reloading press is turned off and unplugged.
 2. Remove any existing die from the press.
 3. Carefully insert the Seater Head into the die holder of the reloading press.
 4. Securely tighten the Seater Head in place to prevent movement during use.
- **Usage:**
 1. Prepare your cartridge case and bullet according to your reloading specifications.
 2. Place the cartridge case in the reloading press.
 3. Align the bullet with the cartridge case and gently lower the Seater Head to initiate the seating process.
 4. Apply consistent and gentle pressure to seat the bullet properly.
 5. Inspect the seated bullet for proper alignment and depth before proceeding to the next step in your reloading process.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local waste disposal regulations.
- Do not throw the Seater Head in regular household waste. Check for recycling options for brass components.
- Ensure that all reloading materials and components are disposed of safely to prevent environmental contamination.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com for additional support and resources.

Thank you for adhering to these safety guidelines. Your safety and satisfaction are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk