

Seater Head 5,60/.223-R70

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 5,60/.223-R70](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017390
- Mfr. No.: 3000054V-05.60-R070
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R70
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R070

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Seater Head 5,60/.223R70](#)
- [About Us](#)

Safety Instruction Guide for Seater Head 5,60/.223R70

Introduction

Thank you for choosing the Seater Head 5,60/.223R70. This product is designed for precision bullet seating in reloading applications. To ensure your safety and the proper functioning of the product, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible equipment.
- Always follow the manufacturer's instructions and recommendations.
- Store the Seater Head in a dry and secure place, out of reach of children.
- Regularly inspect the Seater Head for any signs of damage or wear before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses and gloves, when handling reloading equipment.
- Avoid using the Seater Head if you are under the influence of drugs or alcohol.
- Keep work areas wellventilated to avoid inhaling any dust or fumes.
- Do not exceed the recommended specifications for reloading to prevent accidents.
- Use caution when handling components that may be sharp or have edges.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and free from debris.
- Carefully remove the Seater Head from its packaging.
- Align the Seater Head with the die body of your reloading press, ensuring a snug fit.
- Tighten the Seater Head securely, following the manufacturer's instructions.

2. Usage:

- Before starting, ensure that you have all necessary components ready for reloading.
- Adjust the Seater Head to the required depth for bullet seating as specified in your reloading manual.
- Place a cartridge case in the press and activate the press to seat the bullet.
- Check for proper seating depth and alignment after each operation.
- If any issues arise, stop using the Seater Head and consult the manufacturer's guidelines.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or no longer usable.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further support regarding the Seater Head 5,60/.223R70, please refer to the manufacturer's website or contact the manufacturer's customer service.

By following these safety guidelines and instructions, you can ensure a safe and effective reloading experience. Thank you for prioritizing safety in your reloading practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk