

Seater Head 5,60/.223-R103

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 5,60/.223-R103
- Manufacturer: TRIEBEL
- Product no.: EU2017392
- Mfr. No.: 3000054V-05.60-R103
- Diameter (in): 0.223
- Diameter mm: 5,60
- Radius: R10
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.60-R103

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 5,60/.223R103. This guide provides essential safety instructions to ensure the safe use of the product. Please read this document carefully before using the seater head to understand the safety precautions and proper handling techniques.

General Safety Guidelines

- Ensure that you are familiar with the operation of reloading equipment before using this product.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves while handling reloading tools.
- Keep the seater head and all reloading components out of reach of children and unauthorized persons.
- Regularly inspect the seater head for wear or damage. Do not use if any defects are found.
- Store the seater head in a dry, cool place to prevent corrosion and damage.

Specific Safety Precautions for Use

- Use the seater head only with compatible reloading dies from Triebel Waffenwerkzeuge.
- Always ensure that the reloading press is securely mounted and stable before use.
- Avoid overtightening the seater head, as this may cause damage to the threads or lead to inaccurate bullet seating.
- Do not attempt to modify or repair the seater head. Contact the manufacturer for any necessary repairs or replacements.
- Follow the manufacturer's recommendations for bullet types and weights to ensure optimal performance and safety.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and disconnected from any power source.
- Remove the old seater head from the die by turning it counterclockwise.
- Install the new seater head by threading it into the die and tightening it gently until secure.
- Verify that the seater head is aligned correctly with the die.

2. Usage:

- Adjust the seating depth according to the specifications provided for the bullet you are using.
- Place the cartridge case in the shell holder and ensure it is seated correctly.
- Operate the reloading press smoothly and steadily to seat the bullet without jerking or sudden movements.
- Inspect each completed cartridge for proper bullet seating and overall quality.

Disposal Instructions

- Dispose of any defective or damaged seater heads in accordance with local regulations.
- Do not throw the seater head into regular waste. Instead, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional information regarding the Seater Head 5,60/.223R103, please refer to the manufacturer's website at www.triebelreloading.com. Here, you will find resources for product support, safety updates, and recall information.

By following these safety instructions, you can ensure a safe and effective reloading experience. Always prioritize safety and stay informed about best practices in reloading. Thank you for your attention to these important guidelines.