

Seater Head 5,70/.228-K10,3

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 5,70/.228-K10,3](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017393
- Mfr. No.: 3000054V-05.70-K10.3
- Diameter (in): 0.228
- Diameter mm: 5,70
- Radius: K10
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-05.70-K10.3

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Seater Head 5,70/.228K10,3](#)
- [About Us](#)

Safety Instruction Guide for Seater Head 5,70/.228K10,3

Introduction

Thank you for choosing the Seater Head 5,70/.228K10,3. This product is designed to provide you with precision bullet seating for your reloading needs. To ensure your safety and the proper use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Inspect the Seater Head for any damage before each use. Do not use if damaged.
- Keep the Seater Head out of reach of children and unauthorized users.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling ammunition components.
- Ensure you are in a wellventilated area when reloading to avoid inhaling any dust or fumes.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure the Seater Head is compatible with your reloading dies. Use the manufacturer's website to verify compatibility.
- Do not exceed the recommended load specifications for your ammunition.
- Handle all reloading components with care to prevent accidental discharge.
- Always work with a clear and organized workspace to avoid distractions.
- Follow local regulations regarding the storage and handling of ammunition components.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Remove the existing seater head from your reloading die.
- Carefully install the Seater Head 5,70/.228K10,3 into the die, ensuring it is securely fastened.
- Check that the Seater Head is properly aligned with the die.

2. Usage:

- Set up your reloading press according to the manufacturer's guidelines.
- Place the cartridge case into the press and ensure it is seated correctly.
- Insert the bullet into the case mouth.
- Operate the press to seat the bullet gently and evenly.
- After use, clean the Seater Head and store it in a safe place.

Disposal Instructions

- Dispose of any damaged or unusable components in accordance with local regulations.
- Do not dispose of ammunition components in regular household waste.
- Contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the manufacturer's website or contact your local distributor.

By following these safety guidelines and instructions, you can ensure a safe and effective experience with your Seater Head 5,70/.228K10,3. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk