

Seater Head 6,00/.243-K9

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,00/.243-K9
- Manufacturer: TRIEBEL
- Product no.: EU2017394
- Mfr. No.: 3000054V-06.00-K09
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: K9
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-K09

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,00/.243K9. This product is designed for precision bullet seating and is made from highquality brass. It is essential to follow the safety guidelines and instructions provided in this manual to ensure safe and effective use.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible original dies from Triebel Waffenwerkzeuge.
- Always handle the Seater Head with care to avoid injuries or damage.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the use and handling of reloading equipment.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the Seater Head.
- Ensure that your workspace is clean and free from distractions.
- Do not exceed the recommended specifications for the Seater Head, including the diameter and radius.
- Avoid using the Seater Head if you notice any irregularities or defects.
- Always ensure that the bullet is properly aligned before seating to prevent accidents.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Visit the manufacturer's website www.triebelreloading.com to select the correct seater head based on your specific needs.

2. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing seater head from your die.
- Carefully install the Seater Head into the die, ensuring it is securely fastened.
- Check that the Seater Head is properly aligned with the die.

3. Usage:

- Prepare your cartridges according to standard reloading procedures.
- Place the bullet into the case mouth, ensuring it is properly seated.
- Operate the reloading press slowly and steadily to seat the bullet.
- After seating, inspect the cartridge for proper alignment and seating depth.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.
- If you are discarding the Seater Head, ensure that it is not accessible to children or pets.
- Recycle materials whenever possible, following local recycling guidelines.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Seater Head, please refer to the manufacturer's website or contact your local retailer.

By following these guidelines and instructions, you can ensure a safe and effective experience with your Seater Head 6,00/.243K9. Thank you for prioritizing safety in your reloading activities.