

Seater Head 6,00/.243-R35

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,00/.243-R35
- Manufacturer: TRIEBEL
- Product no.: EU2017396
- Mfr. No.: 3000054V-06.00-R035
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: R35
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-R035

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for purchasing the Seater Head 6,00/.243R35. This guide provides essential safety instructions and information to ensure the safe and effective use of this product. Please read this manual carefully before using the seater head.

General Safety Guidelines

- Ensure that you are familiar with the operation of reloading equipment before using this product.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading tools.
- Keep the work area clean and organized to prevent accidents.
- Store the seater head in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the seater head for any signs of wear or damage before use.

Specific Safety Precautions for Use

- Only use the Seater Head with compatible dies from Triebel Waffenwerkzeuge.
- Follow the manufacturer's instructions for installation and usage to avoid improper handling.
- Avoid using excessive force when seating bullets to prevent damage to the seater head and ensure proper alignment.
- Do not exceed the recommended specifications for the seater head, including the diameter and radius.
- If you experience any issues during use, stop immediately and consult the manufacturer for guidance.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and properly set up.
- Remove any existing seater head from the die.
- Carefully install the Seater Head 6,00/.243R35 into the die, ensuring it is securely fastened.
- Verify that the seater head is aligned correctly before proceeding.

2. Usage:

- Prepare your cartridges and bullets according to standard reloading practices.
- Place the cartridge in the die and insert the bullet into the case mouth.
- Gently lower the press handle to seat the bullet. Use consistent pressure to achieve optimal results.
- After seating, check the cartridge for proper bullet alignment and seating depth.
- Repeat the process for additional cartridges as needed.

Disposal Instructions

- Dispose of any damaged or wornout seater heads in accordance with local regulations.
- Do not dispose of the seater head in regular household waste. Instead, check for recycling options or designated disposal sites.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head 6,00/.243R35, please refer to the manufacturer's website or contact their customer support for assistance.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your Seater Head 6,00/.243R35. Always prioritize safety and consult the manufacturer for any uncertainties. Thank you for choosing our product.