

Seater Head 6,00/.243-R45

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,00/.243-R45
- Manufacturer: TRIEBEL
- Product no.: EU2017397
- Mfr. No.: 3000054V-06.00-R045
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: R45
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-R045

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 6,00/.243R45. This guide provides essential safety instructions and usage information to ensure a safe and effective experience while using this product. Please read all sections carefully before use.

General Safety Guidelines

- Ensure the product is used in a safe environment, free from hazards.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for any signs of wear or damage before use.
- Follow all local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- Use only with original dies from Triebel Waffenwerkzeuge to ensure compatibility and safety.
- Always check the compatibility of the Seater Head with your specific reloading setup before use.
- Avoid overtightening the Seater Head during installation, as this may cause damage or affect performance.
- Do not exceed the recommended load specifications for your ammunition.
- Be cautious of any potential risks associated with handling brass components, such as sharp edges.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the reloading die.
- Carefully thread the Seater Head into the die, ensuring it is securely in place but not overtightened.
- Adjust the seating depth according to your specific requirements.

2. Usage:

- Prepare your brass cases and bullets as per standard reloading practices.
- Insert a brass case into the reloading press and ensure it is properly aligned.
- Place a bullet into the case mouth.
- Activate the reloading press to seat the bullet. Monitor the process to ensure proper alignment and seating.
- Inspect the completed cartridges for proper bullet seating and alignment.

Disposal Instructions

- Dispose of any defective or damaged Seater Heads in accordance with local waste disposal regulations.
- If the product is no longer needed, consider recycling the brass material where facilities are available.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product support, please refer to the manufacturer's website or

contact your local distributor.

Thank you for prioritizing safety while using the Seater Head 6,00/.243R45. Your adherence to these guidelines is essential for a safe and efficient reloading experience.