

Seater Head 6,00/.243-R50

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,00/.243-R50](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017398
- Mfr. No.: 3000054V-06.00-R050
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: R50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-R050

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,00/.243R50. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the Seater Head is compatible with your reloading dies.
- Keep the Seater Head away from children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Do not use the Seater Head if it appears damaged or if any components are missing.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use protective eyewear when operating any reloading equipment, including the Seater Head.
- Ensure that your work area is clean and free from distractions.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head or cartridges.
- Store the Seater Head in a dry, cool place when not in use to prevent corrosion.

Instructions for Installation and Usage

1. Compatibility Check

- Verify that the Seater Head is suitable for your reloading dies from Triebel Waffenwerkzeuge.
- Use the tool on the manufacturer's website to select the correct seater head.

2. Installation

- Carefully remove the Seater Head from its packaging.
- Attach the Seater Head to the reloading die according to the manufacturer's instructions.
- Ensure that it is securely fastened before use.

3. Usage

- Place the cartridge case in the reloading press.
- Insert the bullet into the case mouth.
- Operate the press gently to seat the bullet. Ensure that the bullet is aligned properly for optimal performance.
- Check the seating depth for accuracy after each round.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in general waste if it is damaged or contains hazardous materials.
- Consider recycling options for brass components if available in your area.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's website or contact their customer service.

By following these guidelines, you can ensure safe and effective use of the Seater Head 6,00/.243R50. Always prioritize safety and compliance with the EU General Product Safety Regulation for your wellbeing and that of others. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk