

Seater Head 6,00/.243-R53

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,00/.243-R53](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017399
- Mfr. No.: 3000054V-06.00-R053
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: R53
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-R053

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,00/.243R53. This guide provides essential safety instructions and usage information to ensure your safety and the optimal performance of your product. Please read this guide carefully before use.

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of damage or wear before use.
- Do not use the Seater Head if it appears damaged or malfunctioning.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible original dies from Triebel Waffenwerkzeuge.
- Ensure that the Seater Head is properly attached to the reloading press before use.
- Avoid applying excessive force when seating bullets to prevent damage to the Seater Head or cartridges.
- Always wear appropriate safety gear, including eye protection, when reloading ammunition.
- Follow all local laws and regulations regarding ammunition reloading and handling.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Carefully remove the existing seater head from the reloading press.
- Align the Seater Head with the mounting point on the reloading press.
- Securely fasten the Seater Head in place according to the manufacturer's specifications.

2. Usage:

- Verify that the correct seater head is selected using the tool on the manufacturer's website: www.triebelreloading.com.
- Prepare your cartridges and bullets according to standard reloading practices.
- Gently insert the bullet into the cartridge case and position it under the Seater Head.
- Slowly and steadily operate the reloading press to seat the bullet into the cartridge.
- Inspect the seated bullet for proper alignment and depth before proceeding with further reloading steps.

Disposal Instructions

- Dispose of any damaged or unusable Seater Heads in accordance with local waste disposal regulations.
- Do not dispose of the Seater Head in regular household waste if it contains hazardous materials.
- Consider recycling options available in your area for brass components.

Contact Information for Further Support

For any inquiries related to safety or product support, please refer to the manufacturer's website or reach out to

your local distributor.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk