

Seater Head 6,00/.243-R60

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,00/.243-R60
- Manufacturer: TRIEBEL
- Product no.: EU2017400
- Mfr. No.: 3000054V-06.00-R060
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: R60
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-R060

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,00/.243R60 by TRIEBEL. This guide provides essential safety instructions and usage information to ensure safe and effective operation of the product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose.
- Always follow the manufacturer's instructions for safe handling and operation.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for wear or damage before use.
- Report any unsafe conditions or accidents to the relevant authorities immediately.
- Stay informed about product recalls or safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when using the Seater Head.
- Ensure that the working area is clean and free from obstructions.
- Do not exceed the recommended specifications for your reloading equipment.
- Avoid using the Seater Head if you are tired or under the influence of substances that could impair judgment.
- Handle all components, including bullets and cartridges, with care to avoid accidental discharge or injury.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials before starting the installation.
- Ensure that your reloading press is compatible with the Seater Head.

2. Installation:

- Remove the existing seater head from your reloading die.
- Carefully install the Seater Head by following these steps:
 - Align the Seater Head with the die threads.
 - Screw the Seater Head into the die until secure, but do not overtighten.
- Check for proper alignment and functionality.

3. Usage:

- Adjust the Seater Head according to your desired bullet seating depth.
- Use the tool on the manufacturer's website to select the correct configuration for your needs.
- Begin the reloading process, ensuring that each bullet is seated gently and precisely.
- Monitor the seating process for any irregularities or issues.

Disposal Instructions

- Dispose of any used or damaged Seater Heads in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options for brass components where available.

Contact Information for Further Support

For further information or assistance, please refer to the manufacturer's website at www.triebelreloading.com. Here, you can find additional resources, including product specifications and safety updates.

By adhering to these safety instructions, you can ensure a safe and effective experience with your Seater Head 6,00/.243R60. Thank you for prioritizing safety in your reloading practices.