

Seater Head 6,00/.243-R80

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,00/.243-R80
- Manufacturer: TRIEBEL
- Product no.: EU2017401
- Mfr. No.: 3000054V-06.00-R080
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: R80
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-R080

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,00/.243R80. This product is designed for precision bullet seating and is made from highquality brass, ensuring durability and effectiveness. To ensure your safety and the proper use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always read the product manual before use.
- Ensure that the product is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use the Seater Head only with compatible original dies from Triebel Waffenwerkzeuge.
- Ensure that the diameter of the Seater Head matches the specifications of your cartridges.
- Handle the Seater Head with care to avoid injury from sharp edges.
- Do not exceed the recommended specifications for bullet seating to prevent potential hazards.
- Always wear safety glasses when using reloading equipment to protect your eyes from debris.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials, including the Seater Head, reloading dies, and cartridges.
- Ensure your work area is clean and welllit.

2. Installation:

- Remove any existing Seater Head from your die.
- Carefully install the new Seater Head into the die, ensuring it is securely fastened.
- Check that the Seater Head is properly aligned and functioning.

3. Usage:

- Set the die to the appropriate settings based on your cartridge specifications.
- Insert the cartridge into the die and gently lower the press handle.
- Monitor the seating process for any irregularities and adjust as necessary.
- After seating, inspect the cartridges for proper alignment and seating depth.

4. PostUse:

- Clean the Seater Head and die after use to prevent residue buildup.
- Store the Seater Head in a safe location, away from moisture and direct sunlight.

Disposal Instructions

- Dispose of the Seater Head responsibly according to local regulations.
- Do not dispose of the product in general waste if it is damaged or broken.

- Consider recycling options for brass materials where applicable.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com for support and additional information.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Seater Head 6,00/.243R80. Thank you for your attention to these guidelines.