

Seater Head 6,00/.243-R115

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,00/.243-R115
- Manufacturer: TRIEBEL
- Product no.: EU2017403
- Mfr. No.: 3000054V-06.00-R115
- Diameter (in): 0.243
- Diameter mm: 6,00
- Radius: R11
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.00-R115

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,00/.243R115. This product is designed to enhance your reloading experience by ensuring precise and gentle bullet seating. To ensure your safety and the effective use of this product, please read and follow the guidelines outlined in this instruction manual.

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Use the Seater Head only with compatible original dies from Triebel Waffenwerkzeuge.
- If you experience any issues or abnormalities during use, stop immediately and consult the manufacturer.

Specific Safety Precautions for Use

- When handling the Seater Head, wear appropriate safety gear, such as safety glasses and gloves.
- Ensure that your work area is welllit and free from clutter to prevent accidents.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head and ensure proper alignment.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius, as this may lead to malfunction or injury.
- Always follow safe reloading practices, including proper storage of all components and tools.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and components required for reloading.
- Ensure that the work area is clean and organized.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Attach the Seater Head to the reloading die according to the manufacturer's instructions.
- Ensure that the Seater Head is securely fastened and properly aligned.

3. Usage:

- Insert the cartridge case into the reloading press.
- Place the bullet on top of the cartridge case.
- Slowly lower the ram of the reloading press to seat the bullet.
- Monitor the bullet alignment and seating depth to ensure accuracy.
- After use, clean the Seater Head to remove any residue or debris.

4. PostUsage:

- Store the Seater Head in a safe and dry location when not in use.
- Regularly check for any signs of wear or damage, and replace if necessary.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or broken.
- Check with local authorities or recycling centers for proper disposal methods.

Contact Information for Further Support

For any inquiries or support related to the Seater Head, please refer to the manufacturer's website for contact details and additional resources.

Thank you for following these safety instructions. Your adherence to these guidelines will help ensure a safe and effective reloading experience.