

Seater Head 6,50/.264-R23

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,50/.264-R23
- Manufacturer: TRIEBEL
- Product no.: EU2017406
- Mfr. No.: 3000054V-06.50-R023
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R23
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R023

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Seater Head 6,50/.264R23](#)

Safety Instruction Guide for Seater Head 6,50/.264R23

Introduction

Thank you for choosing the Seater Head 6,50/.264R23. This product is designed for precision bullet seating and is made from highquality brass. It is essential to follow the safety guidelines outlined in this document to ensure safe usage and optimal performance. This guide complies with the EU General Product Safety Regulation (GPSR) to provide you with the necessary information for safe handling and operation.

General Safety Guidelines

- Always read and understand this safety instruction guide before using the Seater Head.
- Ensure that you are using the product for its intended purpose as specified by the manufacturer.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for any signs of wear or damage to the product before use.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls or safety alerts by visiting the EU Safety Gate platform.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Risk of injury if the product is used improperly.
 - Risk of damage to the firearm if the seater head is not correctly matched to the die.
- **Avoiding Hazards:**
 - Always ensure the Seater Head is securely attached to the reloading die before use.
 - Do not exceed the recommended specifications for bullet seating.
 - Use appropriate protective gear, such as safety glasses, when handling reloading equipment.
 - Follow the manufacturer's instructions for selecting the correct seater head for your specific application.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and not in operation.
- Select the correct seater head for your application using the tool on the manufacturer's website: www.tribelreloading.com.
- Carefully attach the Seater Head to the reloading die, ensuring a secure fit.
- Check that the seater head is aligned properly for optimal bullet seating.

2. Usage:

- Prepare your cartridges according to standard reloading practices.
- Place the bullet in the cartridge case and insert it into the reloading press.
- Gradually apply pressure to the handle to seat the bullet. Monitor the process to ensure proper alignment and seating depth.
- After use, clean the seater head to remove any residue or debris.

Disposal Instructions

- Dispose of the Seater Head responsibly in accordance with local regulations.
- Do not dispose of the product in general household waste.

- Consider recycling options for brass materials where available.

Contact Information for Further Support

For any inquiries or concerns regarding the Seater Head 6,50/.264R23, please refer to the manufacturer's website for contact information and support resources.

Thank you for prioritizing safety and following these guidelines to ensure a safe reloading experience.