

Seater Head 6,50/.264-R30

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,50/.264-R30](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017407
- Mfr. No.: 3000054V-06.50-R030
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R30
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R030

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R30. This guide provides essential safety instructions to ensure the safe use of this product. Please read and follow all instructions carefully to avoid hazards and ensure optimal performance.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any visible damage before use. Do not use if damaged.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling the Seater Head.
- Be aware of the potential hazards associated with reloading ammunition and follow all relevant safety practices.

Specific Safety Precautions for Use

- **Compatibility:** Verify compatibility with your reloading setup to avoid malfunctions.
- **Handling:** Handle the Seater Head carefully to prevent injury. Avoid dropping or mishandling.
- **Storage:** Store the Seater Head in a dry, cool place when not in use to prevent corrosion.
- **Cleaning:** Clean the Seater Head regularly using appropriate cleaning agents to maintain performance.
- **Monitoring:** Regularly check for wear and tear to ensure continued safe operation.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged.
- Remove any existing seater head from the die.
- Insert the Seater Head into the die, ensuring it is securely fastened.
- Adjust the seating depth according to your specifications.

2. Usage:

- Prepare your cartridge cases as per standard reloading practices.
- Place the bullet in the case mouth.
- Operate the reloading press to seat the bullet gently. Monitor the process for any irregularities.
- After use, remove the Seater Head and clean as necessary.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or nonfunctional.
- Contact local recycling centers for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please refer to the manufacturer's website or customer support resources.

By following these guidelines, you can ensure a safe and effective reloading experience with your Seater Head

6,50/.264R30. Always prioritize safety and compliance with applicable regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk