

Seater Head 6,50/.264-R50

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,50/.264-R50
- Manufacturer: TRIEBEL
- Product no.: EU2017409
- Mfr. No.: 3000054V-06.50-R050
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R050

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R50. This product is designed to provide precision and reliability in bullet seating for your reloading needs. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the Seater Head is used only with original dies from Triebel Waffenwerkzeuge.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the Seater Head and all reloading components out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the relevant authorities immediately.
- Regularly check for product recalls or safety updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Inspect the Seater Head for any visible damage or defects before each use. Do not use if damaged.
- Ensure that the Seater Head is properly secured to the reloading press before use to prevent accidents.
- Avoid overtightening the Seater Head, as this may cause damage to the equipment or lead to inaccurate bullet seating.
- Use the Seater Head only for its intended purpose—bullet seating. Do not use it for any other applications.
- Follow all manufacturer guidelines regarding the specific caliber and type of bullets being seated.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the reloading press.
- Clean the threads of the reloading press to ensure a proper fit.
- Carefully screw the Seater Head onto the reloading press until it is snug. Do not apply excessive force.
- Verify that the Seater Head is aligned correctly with the die and press.

2. Usage:

- Prepare your cartridge cases and bullets according to standard reloading practices.
- Adjust the Seater Head to the desired seating depth as per your reloading specifications.
- Place the cartridge case in the press and insert the bullet into the case mouth.
- Activate the press to seat the bullet. Ensure that the press operates smoothly without resistance.
- After seating, check the cartridge for proper bullet seating depth and alignment.

3. PostUsage:

- After use, clean the Seater Head to remove any debris or residue.
- Store the Seater Head in a dry, safe location away from children and unauthorized users.

Disposal Instructions

- Dispose of the Seater Head according to local regulations for electronic waste and metal recycling.
- Do not dispose of the Seater Head in regular household waste.
- If the Seater Head is damaged beyond repair, contact your local waste management authority for proper disposal guidelines.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com for additional support and resources.