

Seater Head 6,50/.264-R60

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,50/.264-R60
- Manufacturer: TRIEBEL
- Product no.: EU2017411
- Mfr. No.: 3000054V-06.50-R060
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R60
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R060

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R60. This product is designed to provide precision and reliability in bullet seating for your reloading needs. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always ensure that the Seater Head is compatible with your reloading die before use.
- Inspect the Seater Head for any damage or defects before each use.
- Use the Seater Head only for its intended purpose: bullet seating in reloading applications.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Ensure that your workspace is clean and free from distractions while using the Seater Head.
- Follow all local laws and regulations regarding ammunition and reloading practices.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when handling the Seater Head.
- Do not modify the Seater Head or use it in a manner not intended by the manufacturer.
- Be aware of potential hazards when working with firearms and ammunition, including the risk of accidental discharge.
- Always doublecheck that your reloading setup is secure before beginning the seating process.
- Avoid overtightening the Seater Head during installation to prevent damage to the die or equipment.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the die.
- Carefully screw the Seater Head into the die, making sure it is aligned properly.
- Tighten the Seater Head securely, but do not overtighten.
- Confirm that the Seater Head is properly seated in the die before proceeding.

2. Usage

- Prepare your cartridge cases according to your reloading recipe.
- Insert a bullet into the case mouth.
- Position the cartridge under the Seater Head in the reloading press.
- Activate the press to seat the bullet. Ensure smooth operation without excessive force.
- Check the overall length of the cartridge after seating to ensure it meets your specifications.
- Repeat the process for additional cartridges as needed.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste if it is damaged or defective.
- Consider recycling options for brass components where available.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or its safe use, please refer to the manufacturer's website or contact your local retailer for assistance.

By following these safety instructions, you can ensure a safer reloading experience with your Seater Head 6,50/.264R60. Thank you for prioritizing safety in your reloading practices.