

Seater Head 6,50/.264-R65

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,50/.264-R65
- Manufacturer: TRIEBEL
- Product no.: EU2017412
- Mfr. No.: 3000054V-06.50-R065
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R65
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R065

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R65. This product is designed for precision bullet seating, ensuring optimal accuracy and performance. Please read this safety instruction guide carefully to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that you are familiar with the product before use.
- Always follow the manufacturer's instructions for installation and usage.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear. Do not use if damaged.
- Report any unsafe products or incidents to the relevant authorities.
- Stay updated on product recalls through the EU Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses and gloves, when handling the Seater Head.
- Use the product only for its intended purpose as specified by the manufacturer.
- Ensure that the Seater Head is securely attached to the reloading die before use.
- Avoid excessive force when seating bullets to prevent damage to the product and ensure safety.
- Keep hands and other body parts clear of the working area during operation.
- Store the Seater Head in a dry, cool place when not in use to prevent corrosion.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and free from debris.
- Carefully attach the Seater Head to the reloading die by following the manufacturer's guidelines.
- Tighten the Seater Head securely but do not overtighten, as this may cause damage.

2. Usage:

- Prepare your cartridge case and bullet for seating.
- Adjust the die according to the specifications for your specific cartridge.
- Place the cartridge case in the reloading press and align it properly.
- Insert the bullet into the case mouth.
- Slowly and steadily operate the press to seat the bullet. Avoid applying excessive force.
- After seating, inspect the cartridge for proper bullet alignment and seating depth.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal waste.
- Do not dispose of any product components in regular household waste.
- Check with local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding safety, usage, or product performance, please refer to the manufacturer's website or contact the appropriate support channels provided by the manufacturer.

Thank you for your attention to these safety instructions. Your safety is our priority, and we wish you a successful and enjoyable reloading experience.