

Seater Head 6,50/.264-R70

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,50/.264-R70](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017413
- Mfr. No.: 3000054V-06.50-R070
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R70
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R070

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R70 by TRIEBEL. This guide provides essential safety instructions and usage information to ensure a safe and effective experience with your product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible original dies from Triebel Waffenwerkzeuge.
- Always inspect the Seater Head for any signs of damage or wear before use.
- Keep the product out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding the use of reloading equipment.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use protective eyewear when operating the reloading equipment to protect against potential debris.
- Ensure that your work area is clean and welllit to avoid accidents.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Handle all components with care to avoid injury or damage.
- Always follow the manufacturer's instructions when using the Seater Head.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is securely mounted and stable.
- Select the appropriate Seater Head for your specific caliber using the tool available on the manufacturer's website.
- Carefully install the Seater Head into the reloading die, following the die manufacturer's instructions.

2. Usage

- Prepare your cartridge cases and bullets according to standard reloading practices.
- Adjust the seating depth as required for your specific application.
- Operate the reloading press smoothly and without excessive force to ensure precise bullet seating.
- Regularly check for proper alignment during the reloading process to maintain cartridge concentricity.

Disposal Instructions

- Dispose of any damaged or worn components in accordance with local waste disposal regulations.
- Recycle materials when possible, following local recycling guidelines.
- Do not dispose of the Seater Head in regular household waste if it is considered hazardous.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head or safety inquiries, please refer to the manufacturer's website for additional support and resources.

By following these safety instructions, you can ensure a safe and effective reloading experience with your

Seater Head. Thank you for your attention to safety and compliance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk