

Seater Head 6,50/.264-R72

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,50/.264-R72](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017414
- Mfr. No.: 3000054V-06.50-R072
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R72
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R072

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instructions](#)
- [About Us](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 6,50/.264R72. This product is designed for precision bullet seating, ensuring optimal performance and accuracy. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible original dies from Triebel Waffenwerkzeuge.
- Always handle the Seater Head with care to avoid injury.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- If you notice any defects or malfunctions, discontinue use immediately and contact the manufacturer for guidance.
- Always follow the manufacturer's instructions for usage and maintenance.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves while handling the Seater Head.
- Ensure that your work area is clean and free from clutter to prevent accidents.
- Avoid using the Seater Head in wet or damp conditions to reduce the risk of electrical hazards.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius, to prevent malfunction.
- Ensure that all tools and equipment used in conjunction with the Seater Head are in good working condition.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials.
- Ensure that the work area is welllit and organized.

2. Installation:

- Carefully attach the Seater Head to the compatible die following the manufacturer's guidelines.
- Ensure that the Seater Head is securely fastened to avoid any movement during use.

3. Usage:

- Load the cartridge case into the press and align it properly with the Seater Head.
- Gradually apply pressure to the press handle to seat the bullet gently.
- Monitor the seating process to ensure consistent results and avoid overseating.

4. PostUsage:

- After use, clean the Seater Head to remove any debris or residues.
- Store the Seater Head in a dry, safe location, away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations regarding metal and brass recycling.
- Do not dispose of the Seater Head in household waste to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's official website for contact details and support resources.

By following these safety instructions, you can ensure a safe and effective experience with your Seater Head 6,50/.264R72. Thank you for prioritizing safety and compliance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk