

Seater Head 6,50/.264-R80

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,50/.264-R80](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017415
- Mfr. No.: 3000054V-06.50-R080
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R80
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R080

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R80. This product is designed to enhance your reloading experience with precision and safety. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always ensure the Seater Head is used in accordance with the manufacturer's instructions.
- Store the Seater Head in a safe, dry place away from children and unauthorized users.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Do not modify or alter the Seater Head in any way, as this may compromise safety and performance.
- Always wear appropriate safety gear, including eye protection, when using reloading equipment.

Specific Safety Precautions for Use

- Ensure that the Seater Head is securely attached to the reloading die before use.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head or the bullet.
- Be aware of the potential for lead exposure when handling bullets; wash hands thoroughly after use.
- Keep all components of the reloading setup clean and free from debris to ensure smooth operation.
- Do not leave the Seater Head unattended while in use.

Instructions for Installation and Usage

1. Installation:

- Ensure you have the correct Seater Head for your reloading dies.
- Securely attach the Seater Head to the reloading die according to the manufacturer's instructions.
- Check that the Seater Head is properly aligned and tightened before proceeding.

2. Usage:

- Prepare your cartridges and bullets as per standard reloading procedures.
- Insert the bullet into the case mouth and position it correctly.
- Use the reloading press to gently seat the bullet using the Seater Head.
- Monitor the seating process, ensuring that the bullet is seated to the desired depth without excessive force.

3. PostUse:

- After completing the reloading process, clean the Seater Head and surrounding area.
- Store the Seater Head in a safe location, away from moisture and potential damage.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste if it contains hazardous materials.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional information regarding the Seater Head, please refer to the manufacturer's website at www.triebelreloading.com.

Important Note: This guide is intended to ensure the safe and effective use of the Seater Head. Always prioritize safety and adhere to the guidelines provided. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk