

Seater Head 6,50/.264-R95

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,50/.264-R95](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017416
- Mfr. No.: 3000054V-06.50-R095
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R95
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R095

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R95. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that all safety guidelines are followed while using this product.
- Use the product only for its intended purpose as specified by the manufacturer.
- Always wear appropriate safety gear, including eye protection, when using reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Identification:**

- The Seater Head is designed for precise bullet seating; improper use may lead to accidents or injuries.
- Ensure that the Seater Head is compatible with your reloading die before use.

- **Avoiding Hazards:**

- Do not exceed the recommended specifications for the Seater Head.
- Always check that the Seater Head is securely attached to your reloading equipment before starting.
- Handle all components with care to avoid injury from sharp edges or moving parts.

- **AgeSpecific Warnings:**

- This product is not intended for use by individuals under the age of 18. Ensure adult supervision if used in the presence of minors.

Instructions for Installation and Usage

- **Installation:**

1. Ensure that your reloading press is turned off and unplugged.
2. Select the correct Seater Head using the tool on the manufacturer's website.
3. Carefully attach the Seater Head to your reloading die, ensuring it is securely fastened.
4. Verify that the Seater Head is properly aligned and functioning before proceeding.

- **Usage:**

1. Prepare your cartridges according to the reloading guidelines.
2. Insert the bullet into the cartridge case.
3. With the reloading press engaged, gently lower the Seater Head onto the bullet to seat it correctly.
4. Monitor the seating depth and alignment to ensure optimal performance.
5. After use, clean the Seater Head to maintain its precision and longevity.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the product in regular household waste if it contains hazardous materials.
- Consider recycling options where available.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's website or contact your local distributor.

By adhering to these guidelines, you can ensure a safe and effective experience with your Seater Head 6,50/.264R95. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk