

Seater Head 6,50/.264-R115

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,50/.264-R115
- Manufacturer: TRIEBEL
- Product no.: EU2017417
- Mfr. No.: 3000054V-06.50-R115
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R11
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R115

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R115. This product is designed for precision bullet seating, ensuring optimal performance and accuracy. To ensure your safety and the effective use of this product, please read and follow the safety instructions provided in this guide.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that the product is stored in a dry and safe place, away from children and pets.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves while handling the Seater Head.
- Ensure that the Seater Head is compatible with your reloading dies before use.
- Avoid using excessive force when seating bullets to prevent damage to the Seater Head and ensure consistent bullet seating.
- Keep hands and other body parts clear of moving parts during operation.
- Do not exceed the recommended specifications for bullet seating as indicated by the manufacturer.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials for reloading.
- Ensure that your reloading press is set up according to the manufacturer's guidelines.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Insert the Seater Head into the appropriate die in your reloading press.
- Secure the Seater Head according to the manufacturer's instructions, ensuring it is tightly fitted.

3. Usage:

- Adjust the Seater Head settings according to the specifications for your bullet type.
- Place the cartridge case in the reloading press.
- Gently lower the press handle to seat the bullet, ensuring proper alignment and pressure.
- Inspect the seated bullet for proper seating depth and alignment.

4. PostUsage:

- After use, clean the Seater Head to remove any debris or residue.
- Store the Seater Head in a safe location, away from moisture and extreme temperatures.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations.

- Do not throw the Seater Head in regular household waste. Instead, check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any inquiries or support regarding the Seater Head, please refer to the manufacturer's website or contact their customer service team for assistance.

By following these safety instructions, you will help ensure a safe and effective reloading experience. Always prioritize safety and stay informed about best practices in the use of reloading equipment.