

Seater Head 6,50/.264-R137A

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,50/.264-R137A
- Manufacturer: TRIEBEL
- Product no.: EU2017419
- Mfr. No.: 3000054V-06.50-R137A
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R13
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R137A

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R137A by TRIEBEL. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always read and understand the product instructions before use.
- Use the Seater Head only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for any signs of wear or damage.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading equipment before use.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Do not exceed the recommended specifications for bullet seating.
- Avoid using the Seater Head if it shows signs of damage or wear.
- Use in a wellventilated area to minimize exposure to any potential fumes or dust.
- Be cautious when handling components and tools to prevent injury.

Instructions for Installation and Usage

1. Compatibility Check

- Verify that the Seater Head is suitable for your original dies from Triebel Waffenwerkzeuge.
- Consult the manufacturer's website for compatibility information.

2. Installation

- Ensure your reloading press is clean and free from debris.
- Carefully remove the existing seater head from your die.
- Install the Seater Head by threading it into the die until securely tightened. Do not overtighten.

3. Usage

- Adjust the die to the desired seating depth according to your specifications.
- Place the cartridge case in the shell holder.
- Insert the bullet into the case mouth.
- Operate the reloading press smoothly to seat the bullet.
- Check the cartridge for proper seating and alignment after each use.

4. PostUse Care

- Clean the Seater Head regularly to maintain performance.
- Store the Seater Head in a dry, secure location when not in use.

Disposal Instructions

- Dispose of the Seater Head and any associated materials in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the product is damaged or no longer usable, consider recycling where possible.

Contact Information for Further Support

For any inquiries regarding safety or product information, please consult the manufacturer's official website or customer service resources.

By following these safety instructions, you can ensure a safe and effective experience with your Seater Head 6,50/.264R137A. Thank you for prioritizing safety in your reloading practices.