

Seater Head 6,50/.264-R185

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,50/.264-R185
- Manufacturer: TRIEBEL
- Product no.: EU2017420
- Mfr. No.: 3000054V-06.50-R185
- Diameter (in): 0.264
- Diameter mm: 6,50
- Radius: R18
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.50-R185

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,50/.264R185. This guide provides essential safety information and instructions for the safe use and handling of the product. Please read it carefully to ensure proper usage and compliance with safety regulations.

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any damage before use. Do not use if damaged.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Improper handling may lead to injury or accidents.
 - Use of incompatible components can cause malfunctions.
- **Avoiding Hazards:**
 - Always wear appropriate personal protective equipment, such as safety glasses and gloves, when using the Seater Head.
 - Ensure that your workspace is clean and free from obstructions.
 - Never exceed the recommended specifications for the Seater Head.
 - Do not attempt to modify or alter the Seater Head in any way.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Select the correct Seater Head using the tool on the manufacturer's website, www.triebelreloading.com.
- Carefully install the Seater Head into the reloading die, ensuring it is tightly secured.

2. Usage:

- Verify that the cartridge case is properly positioned in the reloading press.
- Gently lower the Seater Head to seat the bullet. Ensure it aligns with the cartridge case for optimal accuracy.
- After seating, inspect the cartridge for proper bullet alignment and concentricity.
- Store the Seater Head in a clean, dry place when not in use.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of in regular household waste if it is damaged or contains hazardous materials.
- Consider recycling options where available.

Contact Information for Further Support

For any inquiries regarding the safety and use of the Seater Head 6,50/.264R185, please contact the manufacturer directly through their official website or customer service channels.

By following these guidelines, you can ensure a safe and effective experience with your Seater Head. Thank you for your attention to these important safety instructions.