

Seater Head 6,53/.257-K9,3

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,53/.257-K9,3](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017421
- Mfr. No.: 3000054V-06.53-K09.3
- Diameter (in): 0.257
- Diameter mm: 6,53
- Radius: K9,3
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.53-K09.3

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,53/.257K9,3. This product is designed for precision bullet seating and is made from highquality brass to ensure durability and accuracy. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always read the product manual before use.
- Ensure that the Seater Head is compatible with your reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Store the product in a dry and safe location when not in use.
- Regularly inspect the Seater Head for any signs of wear or damage.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Use the Seater Head only for its intended purpose: bullet seating in reloading applications.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves during use.
- Ensure that the reloading area is wellventilated to avoid inhalation of any dust or particles.
- Do not exceed the recommended specifications for the Seater Head.
- Follow all manufacturer guidelines for the safe operation of your reloading equipment.
- Be aware of your surroundings and ensure that no one is in close proximity while operating the equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing seater heads or components from the press.
- Carefully install the Seater Head into the press according to the manufacturer's instructions.
- Tighten the seater head securely but do not overtighten, as this may cause damage.

2. Usage:

- Prepare your cartridges and ensure they are clean and free from any obstructions.
- Adjust the Seater Head to the desired depth according to your reloading specifications.
- Insert the bullet into the case mouth and position it under the Seater Head.
- Activate the reloading press to seat the bullet gently and precisely.
- Inspect the finished cartridge for proper seating and alignment.
- Store any unused components and tools safely after use.

Disposal Instructions

- Dispose of any damaged or unusable Seater Head components in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Check with local waste management authorities for specific disposal guidelines for brass and metal components.

Contact Information for Further Support

For any inquiries regarding the safety and use of the Seater Head, please refer to the manufacturer's website or contact the EUbased support line provided with your product. Always ensure you have the latest information regarding recalls and safety alerts by checking the EU Safety Gate platform.

Thank you for your attention to these guidelines. Your safety is our priority, and following these instructions will help ensure a safe and effective reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk