

Seater Head 6,53/.257-R60

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 6,53/.257-R60](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017422
- Mfr. No.: 3000054V-06.53-R060
- Diameter (in): 0.257
- Diameter mm: 6,53
- Radius: R60
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.53-R060

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,53/.257R60 from Triebel. This guide provides essential safety instructions to ensure the safe use and handling of the product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible equipment and dies from Triebel Waffenwerkzeuge.
- Always follow the manufacturer's instructions for installation and usage.
- Regularly inspect the Seater Head for signs of wear or damage before each use.
- Store the Seater Head in a safe place away from children and unauthorized users.
- Be aware of the potential hazards associated with reloading ammunition and take all necessary precautions.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when reloading.
- Keep your work area clean and organized to prevent accidents.
- Do not attempt to modify or alter the Seater Head in any way.
- Ensure that the Seater Head is securely attached to the reloading press before use.
- Avoid distractions while reloading to maintain focus and accuracy.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged before installation.
- Remove any existing seater head from the press.
- Align the Seater Head with the press and securely fasten it according to the manufacturer's instructions.
- Check that the Seater Head is properly seated and locked in place.

2. Usage:

- Prepare your cartridge cases and bullets as per the reloading instructions.
- Insert the cartridge case into the reloading press.
- Place the bullet on top of the cartridge case.
- Slowly and gently operate the press to seat the bullet using the Seater Head.
- Inspect the seated bullet for proper alignment and depth.
- Repeat the process for additional cartridges, ensuring consistent operation.

Disposal Instructions

- Dispose of any damaged or worn Seater Heads in accordance with local regulations for hazardous waste.
- Avoid throwing the product in regular household waste.
- Contact your local waste disposal service for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product use, please refer to the manufacturer's website or contact the

appropriate support channels.

By following the instructions and guidelines provided in this manual, you will ensure a safer and more effective reloading experience. Always prioritize safety and remain informed about best practices in ammunition reloading.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk