

Seater Head 6,70/.270-K9,5

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,70/.270-K9,5
- Manufacturer: TRIEBEL
- Product no.: EU2017423
- Mfr. No.: 3000054V-06.70-K09.5
- Diameter (in): 0.270
- Diameter mm: 6,70
- Radius: K9,5
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.70-K09.5

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,70/.270K9,5 from TRIEBEL. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read these instructions carefully before using the Seater Head to minimize risks and ensure optimal performance.

General Safety Guidelines

- Ensure that the Seater Head is used only with original dies from Triebel Waffenwerkzeuge.
- Always handle the Seater Head with care to prevent damage to its precisionmachined components.
- Keep the Seater Head out of reach of children and vulnerable individuals to avoid accidental injuries.
- Inspect the Seater Head for any signs of wear or damage before each use. Do not use if damaged.
- Follow all local laws and regulations regarding the use of reloading equipment and components.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Seater Head.
- Ensure that your workspace is clean and free from clutter to prevent accidents.
- Use the Seater Head only for its intended purpose, which is bullet seating in reloading applications.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.
- Be aware of the potential hazards associated with reloading, including the handling of gunpowder and primers.

Instructions for Installation and Usage

- Before installation, ensure that the reloading press is turned off and unplugged.
- Follow these steps to install the Seater Head:
 1. Remove the existing seater head from your reloading die.
 2. Clean the threads of the die and the new Seater Head to ensure proper fit.
 3. Carefully screw the Seater Head into the die, ensuring it is tightened securely but not overtightened.
 4. Adjust the Seater Head to the desired seating depth according to your reloading specifications.
- To use the Seater Head:
 1. Place the cartridge case in the reloading press.
 2. Insert the bullet into the mouth of the cartridge case.
 3. Activate the reloading press to seat the bullet gently and precisely using the Seater Head.
 4. Inspect the seated bullet for proper alignment and depth.
- After use, clean the Seater Head and store it in a safe, dry location.

Disposal Instructions

- Dispose of any damaged or worn components of the Seater Head according to local regulations for hazardous waste.
- Do not dispose of the Seater Head in regular household waste. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For safety inquiries or additional support, please refer to the manufacturer's website at www.triebelreloading.com.

By following these guidelines, you can ensure a safe and effective reloading experience with your Seater Head. Thank you for prioritizing safety in your reloading activities.