

Seater Head 6,70/.270-R50

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,70/.270-R50
- Manufacturer: TRIEBEL
- Product no.: EU2017424
- Mfr. No.: 3000054V-06.70-R050
- Diameter (in): 0.270
- Diameter mm: 6,70
- Radius: R50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.70-R050

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,70/.270R50 by TRIEBEL. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Ensure that your workspace is clean and free of obstructions before beginning any reloading activities.
- Store the Seater Head in a safe place, out of reach of children and pets.
- Inspect the Seater Head for any signs of damage or wear before each use.
- Use personal protective equipment (PPE) such as safety glasses and gloves when reloading ammunition.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading setup by using the manufacturer's tool available at www.triebelreloading.com.
- Only use the Seater Head with original dies from Triebel Waffenwerkzeuge to maintain safety and performance.
- Avoid applying excessive force when seating bullets to prevent damage to the Seater Head or the bullets.
- Keep fingers and hands clear of moving parts during operation to avoid injury.
- Do not modify the Seater Head in any way, as this may compromise safety and performance.

Instructions for Installation and Usage

1. Installation

- Ensure your reloading press is securely mounted and stable.
- Remove any existing seater head from your reloading die.
- Carefully install the Seater Head by following these steps:
 - Align the Seater Head with the die.
 - Tighten securely using the appropriate tools, ensuring it is firmly in place.

2. Usage

- Prepare your cartridges according to the recommended specifications.
- Insert the bullet into the case mouth.
- Activate the reloading press to seat the bullet using the Seater Head.
- Monitor the process closely to ensure proper alignment and seating depth.
- After use, clean the Seater Head to remove any residue or debris.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste.
- Contact local recycling centers for proper disposal methods for brass materials.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact your local distributor for assistance.

Thank you for prioritizing safety while using the Seater Head. Your adherence to these guidelines will help ensure a safe and effective reloading experience.