

Seater Head 6,70/.270-R80

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 6,70/.270-R80
- Manufacturer: TRIEBEL
- Product no.: EU2017425
- Mfr. No.: 3000054V-06.70-R080
- Diameter (in): 0.270
- Diameter mm: 6,70
- Radius: R80
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-06.70-R080

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 6,70/.270R80. This product is designed to ensure precision and ease of use in bullet seating. It is important to follow safety guidelines to ensure safe operation and optimal performance. This guide provides essential safety instructions and usage recommendations to help you use the Seater Head safely and effectively.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Inspect the product for any damage before use. Do not use if damaged.
- Store the Seater Head in a safe, dry place when not in use.
- Always wear appropriate safety gear, such as eye protection, when using the product.
- Be aware of your surroundings and ensure that your workspace is clear and organized.
- Follow all manufacturer instructions and guidelines for use.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading dies. Use the tool on the manufacturer's website to verify compatibility.
- Handle the Seater Head with care to avoid injury from sharp edges or points.
- Keep hands and other body parts clear of moving parts during operation.
- Avoid using excessive force when seating bullets to prevent misalignment and potential accidents.
- Use the Seater Head in a wellventilated area to avoid inhalation of any dust or particles.
- Do not modify the Seater Head or use it for purposes other than intended.

Instructions for Installation and Usage

1. Compatibility Check

- Verify that the Seater Head is compatible with your original dies from Triebel Waffenwerkzeuge using the manufacturer's website.

2. Installation

- Carefully remove the Seater Head from its packaging.
- Ensure that your reloading press is turned off and is in a safe position.
- Install the Seater Head into your reloading die following the manufacturer's instructions.
- Tighten securely without overtightening to avoid damage.

3. Usage

- Prepare your cartridge cases and bullets according to standard reloading procedures.
- Insert the cartridge case into the reloading press.
- Align the bullet with the Seater Head and apply gentle pressure to seat the bullet.
- Check the alignment of the bullet after seating to ensure proper placement.
- Repeat the process for each cartridge while maintaining a clean and organized workspace.

Disposal Instructions

- Dispose of the Seater Head according to local regulations.
- If the product is damaged beyond repair, ensure it is disposed of in a manner that prevents harm to the environment or individuals.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website or contact the EUbased support service provided by the manufacturer.

By following these safety instructions, you can ensure a safe and effective experience with the Seater Head 6,70/.270R80. Always prioritize safety and consult the manufacturer for any additional information or clarification.