

Seater Head 7,00/.284-K10

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-K10
- Manufacturer: TRIEBEL
- Product no.: EU2017427
- Mfr. No.: 3000054V-07.00-K10
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: K10
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-K10

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284K10. This guide provides essential safety instructions to ensure the safe use of this product. Please read and follow these instructions carefully to avoid potential hazards and to maximize your experience with this product.

General Safety Guidelines

- Ensure that the Seater Head is used only for its intended purpose, which is to assist in the precise seating of bullets.
- Always handle the Seater Head with care to avoid physical injuries.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- In case of any malfunction or damage, discontinue use immediately and consult a professional.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when using the Seater Head.
- Ensure that the work area is clean and free from clutter to prevent accidents.
- Do not exceed the recommended specifications for bullet seating as indicated by the manufacturer.
- Be aware of the potential hazards associated with reloading ammunition, including the risk of explosion or injury from improper handling.
- Follow all local laws and regulations regarding the reloading of ammunition.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is compatible with the Seater Head.
- Carefully screw the Seater Head into the reloading die as per the manufacturer's instructions.
- Tighten securely but do not overtighten to avoid damage.

2. Usage:

- Prepare your work area by ensuring it is welllit and organized.
- Load the cartridge case into the reloading press according to the manufacturer's guidelines.
- Place the bullet into the cartridge case and align it with the Seater Head.
- Gradually apply pressure to the reloading press to seat the bullet gently. Ensure that the bullet is seated to the desired depth.
- After use, clean the Seater Head to remove any debris or residue.

Disposal Instructions

- Dispose of any damaged or unusable Seater Heads in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste. Instead, contact your local waste management facility for proper disposal methods.
- Ensure that all components are removed from the Seater Head before disposal.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website at

www.triebelreloading.com for additional resources and support.

By following these safety instructions, you can ensure a safe and effective experience with your Seater Head 7,00/.284K10. Thank you for your attention to safety.