

Seater Head 7,00/.284-R50

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-R50
- Manufacturer: TRIEBEL
- Product no.: EU2017429
- Mfr. No.: 3000054V-07.00-R050
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R50
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R050

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R50. This product is designed for precise and gentle bullet seating, enhancing your reloading experience. It is important to follow safety guidelines to ensure safe usage and optimal performance.

General Safety Guidelines

- Always read and understand the product instructions before use.
- Ensure that the Seater Head is compatible with your reloading equipment.
- Use the product only for its intended purpose as specified by the manufacturer.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for wear or damage before each use.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Handle the Seater Head with care to avoid injury.
- Always wear appropriate safety gear, such as safety glasses and gloves, when using the product.
- Ensure that your workspace is welllit and free from clutter to prevent accidents.
- Avoid using the Seater Head in wet or damp conditions to reduce the risk of electrical hazards.
- Follow the manufacturer's instructions for adjusting and using the Seater Head to prevent misuse.

Instructions for Installation and Usage

1. Compatibility Check

- Verify that the Seater Head is suitable for your existing reloading dies from Triebel Waffenwerkzeuge.

2. Installation

- Carefully remove the Seater Head from its packaging.
- Install the Seater Head onto your reloading die, ensuring it is securely fastened.
- Check for proper alignment before proceeding.

3. Usage

- Set the desired bullet seating depth according to your specifications.
- Load the cartridge case into the reloading press.
- Gently lower the Seater Head to seat the bullet into the cartridge case.
- Monitor the process to ensure proper seating and alignment.

4. PostUsage Care

- After use, clean the Seater Head with a soft cloth to remove any residue.
- Store the Seater Head in a dry, safe place away from children and pets.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal products.
- Do not dispose of the product in household waste if it is deemed hazardous or contains harmful materials.

- Consider recycling options for the brass material where applicable.

Contact Information for Further Support

For any safety inquiries or further assistance, refer to the manufacturer's website at www.tribelreloading.com. You can find additional resources and support options there.

By following these safety instructions, you can ensure a safe and effective experience with your Seater Head 7,00/.284R50. Thank you for prioritizing safety in your reloading activities.