

Seater Head 7,00/.284-R55

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 7,00/.284-R55](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017430
- Mfr. No.: 3000054V-07.00-R055
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R55
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R055

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R55. This product is designed for precision bullet seating, ensuring optimal performance and accuracy. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Seater Head for any signs of wear or damage before use.
- Only use the Seater Head with compatible dies from Triebel Waffenwerkzeuge.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the Seater Head is securely attached to the reloading press before use.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, while handling and using the Seater Head.
- Do not exceed the recommended specifications for diameter and radius as indicated in the product details.
- Avoid placing fingers or hands near moving parts during operation to prevent injury.
- Do not modify the Seater Head or use it for any purpose other than intended.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials, including the reloading press and compatible dies.
- Ensure your workspace is clean, organized, and well-lit.

2. Installation:

- Carefully remove the Seater Head from its packaging.
- Attach the Seater Head to the reloading press, ensuring a secure fit.
- Confirm that the Seater Head is properly aligned with the die and press mechanism.

3. Usage:

- Select the correct seater head using the tool available on the manufacturer's website: www.triebelreloading.com.
- Insert the cartridge case into the reloading press.
- Slowly and gently apply pressure to seat the bullet.
- Monitor the seating process to ensure proper alignment and prevent misalignment.

4. PostUse Care:

- After use, clean the Seater Head to remove any residue or debris.
- Store the Seater Head in a safe and dry location, away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations for metal products.
- Do not dispose of in regular household waste. Check with local waste management for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website for additional support and resources.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and effective reloading experience with the Seater Head 7,00/.284R55.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk