

Seater Head 7,00/.284-R90

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-R90
- Manufacturer: TRIEBEL
- Product no.: EU2017432
- Mfr. No.: 3000054V-07.00-R090
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R90
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R090

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R90. This product is designed for precision bullet seating in reloading applications. To ensure your safety and the optimal performance of this product, please read and follow the guidelines outlined in this document.

General Safety Guidelines

- Always handle the Seater Head with care to avoid injury.
- Ensure that you are using the correct seater head for your specific die set.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any signs of damage before use. Do not use if damaged.
- Follow all local laws and regulations regarding ammunition reloading.

Specific Safety Precautions for Use

- Use protective eyewear when operating machinery or tools.
- Ensure that your work area is clean, dry, and welllit.
- Do not exceed the recommended specifications for your reloading setup.
- Avoid distractions while using the Seater Head to maintain focus and safety.
- Store the Seater Head in a safe location when not in use.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head:

- Visit the manufacturer's website at www.tribelreloading.com to select the appropriate seater head for your needs.

2. Installation:

- Make sure your reloading press is turned off and unplugged before installation.
- Remove the existing seater head from the die if applicable.
- Carefully install the Seater Head 7,00/.284R90 into the die, ensuring it is securely fastened.
- Adjust the seating depth as per your specific requirements.

3. Usage:

- Place the cartridge case into the reloading press.
- Ensure the bullet is properly aligned with the Seater Head.
- Apply steady pressure to the press handle to seat the bullet gently.
- Check the bullet seating depth regularly to ensure consistency.

Disposal Instructions

- Dispose of any used or damaged Seater Heads in accordance with local regulations.
- Do not dispose of the Seater Head in regular household waste.
- If the product is beyond use, consider recycling options if available.

Contact Information for Further Support

For any inquiries or concerns regarding the Seater Head, please refer to the manufacturer's website for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and effective reloading experience with the Seater Head 7,00/.284R90. Always prioritize safety and compliance with local regulations during your reloading activities. Thank you for your attention to these important guidelines.