

Seater Head 7,00/.284-R92

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-R92
- Manufacturer: TRIEBEL
- Product no.: EU2017433
- Mfr. No.: 3000054V-07.00-R092
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R92
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R092

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R92. This product is designed to provide precision and accuracy in bullet seating for rifle reloading. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always use the product as intended and in accordance with the manufacturer's instructions.
- Inspect the Seater Head for any damage before use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading equipment and dies.
- Use appropriate personal protective equipment (PPE), such as safety glasses and gloves, during reloading activities.
- Avoid working in a cluttered area to prevent accidents.
- Be cautious of sharp edges and components that may cause injury.
- Do not exceed the recommended specifications for the Seater Head, including diameter and radius.

Instructions for Installation and Usage

1. Compatibility Check:

- Verify that the Seater Head is suitable for your original dies from Triebel Waffenwerkzeuge.
- Use the manufacturer's compatibility tool available on their website.

2. Installation:

- Ensure your reloading press is turned off and unplugged.
- Insert the Seater Head into the appropriate die.
- Securely tighten the Seater Head to prevent movement during use.

3. Usage:

- Load the cartridge case into the reloading press.
- Adjust the seating depth as needed, ensuring the bullet is aligned with the Seater Head.
- Operate the press smoothly and steadily to avoid damaging the bullet or the Seater Head.
- Inspect the seated bullet for proper alignment and depth after each operation.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of in regular household waste if it is damaged or contains hazardous materials.
- Check with local waste management authorities for guidelines on disposing of metal products.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or customer support resources. Ensure that you have the product information ready for any inquiries.

By following these safety instructions, you can ensure a safe and effective reloading experience. Thank you for your attention to safety and for choosing the Seater Head 7,00/.284R92.