

Seater Head 7,00/.284-R115

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 7,00/.284-R115
- Manufacturer: TRIEBEL
- Product no.: EU2017434
- Mfr. No.: 3000054V-07.00-R115
- Diameter (in): 0.284
- Diameter mm: 7,00
- Radius: R11
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-07.00-R115

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 7,00/.284R115. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always use the Seater Head in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the Seater Head for any damage before use. Do not use if damaged.
- Use appropriate personal protective equipment (PPE), such as safety glasses, when handling.
- Be aware of your surroundings to avoid accidents while using the Seater Head.
- Do not exceed the specified diameter and radius limits during use.

Specific Safety Precautions for Use

- Ensure that the Seater Head is compatible with your reloading dies. Use the tool on the manufacturer's website to verify compatibility.
- Use the Seater Head only for its intended purpose of bullet seating.
- Do not modify the Seater Head in any way, as this may compromise safety and performance.
- Always follow safe reloading practices, including proper handling of components and ammunition.
- Store the Seater Head in a dry and secure place when not in use to prevent unauthorized access and damage.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials for reloading.
- Ensure your workspace is clean and organized.

2. Installation:

- Securely attach the Seater Head to the reloading die according to the manufacturer's instructions.
- Check that it is fastened tightly and correctly aligned.

3. Usage:

- Place the cartridge case in the reloading press.
- Insert the bullet into the case mouth.
- Slowly and gently operate the press to seat the bullet using the Seater Head.
- Monitor the process closely to ensure proper seating depth and alignment.

4. PostUse:

- Clean the Seater Head after use to maintain its performance and longevity.
- Store the Seater Head in its original packaging or a secure container.

Disposal Instructions

- Dispose of any damaged or wornout Seater Heads in accordance with local regulations.

- Do not dispose of the Seater Head in regular household waste.
- Check with local recycling programs for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Seater Head, please refer to the manufacturer's contact information available on their website. It is important to stay informed about product safety and any potential recalls.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with the Seater Head 7,00/.284R115. Always prioritize safety and compliance with the EU General Product Safety Regulation. Thank you for your attention to these guidelines.